


5" Air Straight Grinder



No.	Part No.	Description	Q'ty
1	3615S0010	Inlet Bushing (PT)	1
	3615S0011	Inlet Bushing (NPT)	1
2	3615S0020	Throttle Valve Spring	1
3	3615S0030	Sub Throttle Valve	1
4	3615S0040	Throttle Valve Washer	1
5	3615S0050	Throttle Valve	1
6	3615S0060	Throttle Valve Rod	1
7	3615S0070	Throttle Rod Bushing	1
8	3615S0080	Throttle Valve Body	1
9	3615S0090	Throttle Valve Lever	1
10	3615S0100	Lock Spring	1
11	3615S0110	Lock Key	1
12	3615S0120	Set Screw	1
13	3615S0130	Needle Roller	1
14	3615S0140	O-ring	1
15	3615S0150	Cup Nut	1
16	3615S0160	Housing Cover	1
17	3615S0170	Washer	1
18	3615S0180	Spring Washer	2
19	3615S0190	Cap Screw	2
20	3615S0200	Throttle Valve Cover(PT)	1
	3615S0201	Throttle Valve Cover(NPT)	1
21	3615S0210	Strainer	1
22	3615S0220	Throttle Valve Spring	1
23	3615S0230	Throttle Valve Handle	1
24	3615S0240	O-ring	1
25	3615S0250	Throttle Valve	1

No.	Part No.	Description	Q'ty
26	3615S0260	Handle Spring	1
27	3615S0270	Pin	1
28	3615S0280	Housing Cover	1
29	3615S0290	Needle Roller	1
30	3615S0300	Bushing	1
31	3615S0310	Needle Roller	1
32	3615S0320	Governor Spring Holder	1
33	3615S0330	Adjusting Washer (T=0.2)	1
34	3615S0340	Governor Spring	1
35	3615S0350	Governor Valve	1
36	3615S0360	Governor Cage	1
36A	3615S036A	Governor Shaft	1
36B	3615S036B	Nut	1
37	3615S0370	Pin	2
38	3615S0380	Governor Weight	2
39	3615S0390	Bearing Cover	1
40	3615S0400	Ball Bearing	1
41	3615S0410	Cylinder Upper Plate	1
42	3615S0420	Rotor	1
43	3615S0430	Rotor Blade	4
44	3615S0440	Key	1
45	3615S0450	Spring Pin	1
46	3615S0460	Cylinder	1
47	3615S0470	Cylinder Lower Plate	1
48	3615S0480	Ball Bearing	1
49	3615S0490	Coupling	1
50	3615S0500	Spacer	1

No.	Part No.	Description	Q'ty
51	3615S0510	Snap Ring	1
52	3615S0520	Ball Bearing	1
53	3615S0530	Wheel Spindle	1
54	3615S0540	Key	1
55	3615S0550	Exhaust Cover	1
56	3615S0560	Spring Washer	2
57	3615S0570	Cap Screw	2
58	3615S0580	Housing	1
59	3615S0590	Inner Race	1
60	3615S0600	Needle Bearing	1
61	3615S0610	Spindle Bearing Cover	1
62	3615S0620	Felt Ring	1
63	3615S0630	Wheel Flange (A)	1
64	3615S0640	Snap Ring	1
65	3615S0650	Wheel Flange (B)	1
66	3615S0660	Nut	1
67	3615S0670	Nut	1
68	3615S0680	Hexagon Bolt	1
69	3615S0690	Spring Washer	1
70	3615S0700	Nut	1
71	3615S0710	Wheel Guard	1
73	3615S0730	Spanner (41mm)	1
Optional Part (615SH)			
72	3615S0720	Exhaust House Joint	1
72A	3615S072A	House Hold	1
72B	3615S072B	House (1200MM)	1