


2" Angle Grinder



No.	Part No.	Parts Name	Q'ty
101	362C10100	Housing Cover	1
106	362C10600	Grip	1
110	362C11000	Throttle Valve	1
117	362C11700	Throttle Valve Spring	1
120	362C12000	Throttle Value Cover (PT)	1
120	362C12001	Throttle Value Cover (NPT)	1
124	362C12400	Knock Spring	1
B01	362CB0100	Needle Roller	1
J01	362CJ0100	Ball	1
201	362C20100	Housing	1
207	362C20700	Rotor	1
208	362C20800	Rotor Blade	4
209	362C20900	Cylinder	1
(B03)	362CB0300	Spring Pin	1
210	362C21000	Cylinder Upper Plate	1
211	362C21100	Cylinder Lower Plate	1
217	362C21700	Bearing Cover	1
221	362C22100	Spindle Bearing Cover	1
222	362C22200	Felt Ring	1
260	362C26000	Bearing Case	1
301	362C30100	Wheel Spindle	1
303	362C30300	Wheel Flange (A)	1
304	362C30400	Wheel Flange (B)	1
314	362C31400	Wheel Spindle Washer	1
335	362C33500	Wheel Guard	1
D01	362CD0100	Cap Screw	2

No.	Part No.	Parts Name	Q'ty
E01	362CE0100	Spring Washer	2
423	362C42300	Bevel Pinion	1
426	362C42600	Bevel Gear	1
434	362C43400	Bearing Washer	1
440	362C44000	Ring	1
A01	362CA0100	Ball Bearing (606)	1
A02	362CA0200	Ball Bearing (608)	1
A03	362CA0300	Ball Bearing (605)	1
A04	362CA0400	Ball Bearing (6001)	1
H01	362CH0100	Key	1
102	362C10200	Housing Cover	1
140	362C14000	Cup Nut	1
143	362C14300	Housing Cover Packing	1
108	362C10800	Throttle Valve Body	1
109	362C10900	Throttle Valve Bushing	1
113	362C11300	Throttle Valve Rod	1
118	362C11800	Throttle Valve Spring	1
119	362C11900	T.V. Cover Packing	1
122	362C12200	Throttle Valve Cover	1
171	362C17100	Inlet Bushing	1
B04	362CB0400	Spring Pin	1
J02	362CJ0200	O Ring	1
121	362C12100	Throttle Valve Lever	1
183	362C18300	Safety Lock	1
184	362C18400	Safety Lock Spring	1
B02	362CB0200	Spring Pin	1